Tiandy Technologies Co., Ltd.

No.8 Haitai Huake Rd2(Huayuan), Binhai Hi-Tech Zone, Tianjin 300384, China Tel: +86-22-58596037   Fax: +86-22-58596177   en.tiandy.com

How to upgrade customize voice by AudioMaker

Description: This document will show you how to make your own audio in device by AudioMaker

Prerequisites: AudioMaker

Section 1: Device Audio Detection

1. **Device Audio Detection**

    1.1 Enter the device's IP which you want to add.

    1.2 Enter the account and password, and then click 'audio detect'.

    1.3 Set the download route.

Section 2: Uploading audio by Audio Recording

1. **Connect device by Easyddns in Website**

    1.1 Click record button to record audio.

    1.2 Click upload button and then enter the device's account and password.

    1.3 Click Start Packing button to package with location route.

Tiandy Technologies Co., Ltd.

No.8 Haitai Huake Rd2(Huayuan), Binhai Hi-Tech Zone, Tianjin 300384, China Tel: +86-22-58596037 Fax: +86-22-58596177 en.tiandy.com

Section 3: Uploading audio by Speech Synthesis

1. **Uploading audio by Speech Synthesis**

   1.1 Enter the text you want.

   1.2 Customize the audio type you want, then save and auditions.

   1.3 Click 'Start packing' button to package audio, click 'upload' button to upload the audio to device.

Tiandy Technologies Co., Ltd.

No.8 Haitai Huake Rd2(Huayuan), Binhai Hi-Tech Zone, Tianjin 300384, China Tel: +86-22-58596037 Fax: +86-22-58596177 en.tiandy.com

Section 4: Uploading audio by web interface directly

1. Uploading audio by web interface directly

1.1 Upgrade from the web page with the previously packaged upgrade package.